

Title: PHS-FWA System : Interface Specification between Fixed
Wireless Access Controller and Service Node -Analogue
Subscriber Interface -

Version: 02

Date: June 7, 2000

PHS MoU Classification: Unrestricted

List of contents:

1. General
2. Interface
 - 2.1 Function
 - 2.2 DC characteristics
 - 2.3 AC characteristics
 - 2.4 Subscriber cable
 - 2.5 Over voltage and current protection
3. Comments for Implementation
 - 3.1 Power Feeding
4. References
5. Items for Further Study
 - 5.1 Test functions

ANNEX A

Number of pages: 30

PHS MoU Group

c/o Association of Radio Industries and Businesses (ARIB)
14F, Nittochi Bldg., 4-1, Kasumigaseki, 1-choume, Chiyoda-ku, Tokyo 100-0013, Japan
TEL +81-3-5510-8599 FAX +81-3-3592-1103

© PHS MoU Group 2000

History of Revised Versions

| Version | Date | Outline |
|---------|---------------|---|
| 01 | Dec. 17, 1996 | Established |
| 02 | June 7, 2000 | Changed all WLL into FWA. Sub-clause 2.1 is changed. |
| | | |
| | | |
| | | |
| | | |
| | | |
| | | |
| | | |
| | | |

**PHS-FWA System : General Description
of Interface Specifications between Fixed Wireless Access Controller
and Service Node - Analogue Subscriber Interface**

Contents

| | |
|---|----|
| 1. General | 1 |
| 2. Interface..... | 1 |
| 2.1 Function | 1 |
| 2.2 DC characteristics..... | 3 |
| 2.3 AC characteristics..... | 3 |
| 2.4 Subscriber cable..... | 3 |
| 2.5 Over voltage and current protection | 3 |
| 3. Comments for Implementation..... | 4 |
| 3.1 Power Feeding | 4 |
| 4. References | 4 |
| 5. Items for Further Study | 4 |
| 5.1 Test functions | 4 |
| ANNEX A | 5 |
| 1. Definition of Signals, Messages and Timers Examples..... | 5 |
| 2. State Transition Table Examples | 7 |
| 2.1 Individual Subscriber..... | 7 |
| 2.2 Coin Box..... | 7 |
| 2.3 Loop Start PBX..... | 8 |
| 2.4 Ground Start PBX..... | 8 |
| 2.5 DDI PBX..... | 9 |
| 2.6 NTT individual Subscriber | 10 |
| 2.7 NTT DDI PBX..... | 10 |
| 3. Message Sequence Examples..... | 11 |
| 3.1 Originating-Answer (Individual DP Line Sub.) | 11 |

| | |
|---|----|
| 3.2 Originating-Answer (Individual DTMF Line Sub.) | 12 |
| 3.3 Originating-Answer (Loop Start PBX)..... | 13 |
| 3.4 Originating-Answer (Ground Start PBX)..... | 14 |
| 3.5 Release-before Dialling | 15 |
| 3.6 Release-during Dialling | 16 |
| 3.7 Release-During Ringing | 17 |
| 3.8 Call Collision..... | 18 |
| 3.9 Calling Party Release-Individual Sub. Originating | 19 |
| 3.10 Called Party Release-Individual Sub. Originating | 20 |
| 3.11 Terminating-Answer..... | 21 |
| 3.12 Terminating-Ringing Resource Hunt NG..... | 22 |
| 3.13 Terminating-Answer (NTT DDI Spec.) | 23 |
| 3.14 Terminating-Answer (DP type DDI) | 24 |
| 3.15 Terminating-Answer (DTMF Type DDI)..... | 25 |
| 3.16 Calling Party Release-Individual Sub. Terminating..... | 26 |
| 3.17 Called Party Release-Individual Sub. Terminating | 27 |
| 3.18 Hooking Monitoring | 28 |
| 3.19 Meter Pulsing Signal Sending | 29 |
| 3.20 Connection to Howler Tone | 30 |

1. General

This specification describes about analogue subscriber interface between WAC and SN. As analogue subscriber interface should be compatible for PSTN, the actual specification depends on the administrator or operating company.

2. Interface

Following sections describe the items that should be considered in the administrator or operating company's specification regarding WAC analogue subscriber interface.

2.1 Function

WAC shall have the following functions. The administrator or operating company will decide which functions should be implemented.

(1) Voice transmission

transmit voice and modem data in both way.

(2) Loop close sending

send the loop closed to SN.

(3) Loop open sending

send the loop open to SN.

(4) Dial sending

send the dial pulse or DTMF to SN.

(5) Hooking signal sending

send the hooking signal to SN.

(6) Ringing signal detection

detect ringing signal from SN.

(7) Ring trip

send the answer to SN during ringing signal receiving.

(8) Over voltage and current protection

protect over voltage and current from outside.

(9) Test

Further study.

(10) Loop polarity reverse steady signal receiving

receive loop polarity reverse for answer signal.

(11) Loop polarity reverse pulse receiving

receive loop polarity reverse pulse for mate party on hook. This signal is also receipt as metering signal.

(12) Metering signal receiving

receive metering signal. the administrator or operating company shall choose the metering signal type.

i) Loop polarity reverse pulse

ii) 12kHz tone pulse

iii) 16kHz tone pulse

(13) Ground Start Sending

send off hook for ground start PBX.

(14) Calling Line Identification Presentation (CLIP)

receive the signals for CLIP service.

(15) Tone and Signal Reception

The used tone are selected by administrator or operating company.

i) Dial tone

ii) Busy tone

iii) Congestion tone

iv) Ring back tone

v) Howler tone

vi) Announcement

2.2 DC characteristics

The administrator or operating company shall specify the followings;

- (1) loop close and open impedance
- (2) DP sending
- (3) Hooking sending
- (4) Ground start sending
- (5) Loop polarity reverse pulse detection

2.3 AC characteristics

The administrator or operating company shall specify the followings;

- (1) DTMF sending
- (2) Ringing signal input impedance
- (3) Ring trip
- (4) Metering Signal Detection Characteristics
- (5) CND Detection Characteristics
- (6) Transmission Characteristics
 - i) Transmission characteristics
 - ii) Echo suppression

2.4 Subscriber cable

The administrator or operating company shall specify the followings;

- (1) loop resistance
- (2) insulation resistance
- (3) capacitance between wires

2.5 Over voltage and current protection

refer to ITU-T K.20.

3. Comments for Implementation

3.1 Power Feeding

4. References

- (1) ITU-T K.20

5. Items for Further Study

5.1 Test functions

ANNEX A

ANNEX A describes the analogue subscriber interface of WAC application examples.

1. Definition of Signals, Messages and Timers Examples

Figure 1-1/C-IF3.01 shows the WSU functional block diagram.

Table 1-1/C-IF3.01 shows the signal definitions that are used in state transition tables.

Table 1-2/C-IF3.01 shows the state definitions that are used in state transition tables.




Figure 1-1/C-IF3.01 WAC Functional Block Diagram

Table 1-1/C-IF3.01 Signal Definition

| signal | direction | meanings |
|-------------------------|------------|--|
| SN dt | SN to SIF | SN sends DT to WAC. |
| SN bt | SN to SIF | SN sends BT to WAC. |
| SN howler | SN to SIF | SN sends Howler tone to WAC. |
| SN ringing | SN to SIF | SN sends Ringing Signal to WAC> |
| SN normal polarity | SN to SIF | SN makes two wire polarity normal. |
| SN reverse polarity | SN to SIF | SN makes two wire polarity reversal. |
| SN loop closed | SN to SIF | SN makes two wire loop closed. |
| SN loop open | SN to SIF | SN makes two wire loop open. |
| SN dp/dtmf | SN to SIF | SN sends digit dial to WAC using DP or DTMF. |
| SN g on tip | SN to SIF | SN sends ground on tip wire. |
| SN meter pulsing signal | SN to SIF | SN sends meter pulsing signal to WAC. |
| loop closed | SIF to SN | WAC makes two wire loop closed. |
| loop open | SIF to SN | WAC makes two wire loop open. |
| dp/dtmf | SIF to SN | WAC sends meter pulsing signal to SN. |
| normal polarity | SIF to SN | WAC makes two wire polarity normal. |
| reverse polarity | SIF to SN | WAC makes two wire polarity reversal. |
| g on tip with loop | SIF to SN | WAC sends ground on tip wire with loop closed. |
| SEIZURE ACK | SIF to WCI | indicate seizure ack detection at SIF |
| SEIZURE NAK | SIF to WCI | indicate seizure nak detection at SIF |
| RELEASE | SIF to WCI | indicate release detection at SIF |
| ANSWER | SIF to WCI | indicate answer detection at SIF |
| METER PULSING SIGNAL | SIF to WCI | indicate meter pulsing signal detection at SIF |
| REVERSE POLARITY | SIF to WCI | indicate reverse polarity detection at SIF |
| NORMAL POLARITY | SIF to WCI | indicate normal polarity detection at SIF |
| TERMINATING | SIF to WCI | indicate terminating detection at SIF |
| HOWLER | SIF to WCI | indicate howler tone detection at SIF |
| DIGIT DIAL | SIF to WCI | sends digit dial that is receipt at SIF |
| off hook | WCI to SIF | make SIF off hook state. |
| on hook | WCI to SIF | make SIF on hook state |
| digit dial | WCI to SIF | sends digit dial that SIF should send |
| normal polarity | WCI to SIF | makes SIF normal polarity |
| reverse polarity | WCI to SIF | makes SIF reverse polarity |

Table 1-2/C-IF3.01 State Definition

| state | | individual | LS PBX | GS PBX | coin box | DDI PBX | | NTT individual | NTT DDI |
|-------|-------------------------|--------------------------------|--------------------------------|--------------------------------|--------------------------------|--------------------------------|---|--------------------------------|--------------------------------|
| | | | | | | origination | termination | | |
| 0 | idle | loop open | WCS: normal pwr SN: normal pwr | loop open | loop open |
| 1 | off hook | loop closed | WCS: reverse pwr SN: loop closed | loop closed | loop closed |
| 2 | terminating | ringing signal reception | ringing signal reception | ringing signal reception | ringing signal reception | ringing signal reception | WCS: normal pwr SN: loop closed | ringing signal reception | ringing signal reception |
| 3 | clear forward reception | none | none | none | none | none | WCS: reverse pwr SN: loop open | none | none |
| 4 | clear back sending | none | none | none | none | none | WCS: normal pwr SN: loop open | none | none |

2. State Transition Table Examples

2.1 Individual Subscriber

Table 2-1/C-IF3.01 shows the WAC analogue subscribe interface state transition table for individual subscriber.

Table 2-1/C-IF3.01 Interface State Transition Table, Individual subscriber

| state | ST 0 | ST 1 | ST 2 |
|-------------------------|----------------------|-------------------|-------------------|
| event | | | |
| SN dt | / | SEIZURE ACK | / |
| SN bt | / | / | / |
| SN howler | / | / | / |
| SN ringing | TERMINATING, ST 2 | / | / |
| SN normal polarity | / | / | / |
| SN reverse polarity | / | / | / |
| SN loop closed | / | / | / |
| SN loop open | / | / | / |
| SN dp/dtmf | / | / | / |
| SN g on tip | / | / | / |
| SN meter pulsing signal | / | / | / |
| off hook | loop closed, ST 1 | / | loop closed, ST 1 |
| on hook | / | loop closed, ST 0 | / |
| digit dial | / | dp/dtmf | / |
| reverse polarity | / | / | / |
| normal polarity | / | / | / |

- = No state change; / = Unexpected event, no state change;

2.2 Coin Box

Table 2-2/C-IF3.01 shows the WAC analogue subscribe interface state transition table for coin box.

Table 2-2/C-IF3.01 Interface State Transition Table, Coin Box

| state | ST 0 | ST 1 | ST 2 |
|-------------------------|----------------------|----------------------------|-------------------|
| event | | | |
| SN dt | / | SEIZURE ACK | / |
| SN bt | / | / | / |
| SN howler | / | / | / |
| SN ringing | TERMINATING, ST 2 | / | / |
| SN normal polarity | / | / | / |
| SN reverse polarity | / | / | / |
| SN loop closed | / | / | / |
| SN loop open | / | / | / |
| SN dp/dtmf | / | / | / |
| SN g on tip | / | / | / |
| SN meter pulsing signal | / | METER PULSING SIGNAL | / |
| off hook | loop closed, ST 1 | / | loop closed, ST 1 |
| on hook | / | loop closed, ST 0 | / |
| digit dial | / | dp/dtmf | / |
| reverse polarity | / | / | / |
| normal polarity | / | / | / |

- = No state change; / = Unexpected event, no state change;

2.3 Loop Start PBX

Table 2-3/C-IF3.01 shows the WAC analogue subscribe interface state transition table for loop start PBX.

Table 2-3/C-IF3.01 Interface State Transition Table, Loop Start PBX

| state | ST 0 | ST 1 | ST 2 |
|----------------------------|----------------------|---------------------|-------------------|
| event | | | |
| SN dt | SEIZURE ACK | SEIZURE ACK | / |
| SN bt | / | / | / |
| SN howler | / | / | / |
| SN ringing | TERMINATING, ST 2 | / | / |
| SN normal polarity | NORMAL POLARITY | NORMAL POLARITY | / |
| SN reverse polarity | / | REVERSE POLARITY | / |
| SN loop closed | / | / | / |
| SN loop open | / | / | / |
| SN dp/dtmf | / | / | / |
| SN g on tip | / | / | / |
| SN meter pulsing signal | / | / | / |
| off hook | loop closed, ST 1 | / | loop closed, ST 1 |
| on hook | / | loop open, ST 0 | / |
| digit dial | / | dp/dtmf | / |
| reverse polarity | / | / | / |
| normal polarity | / | / | / |

- = No state change; / = Unexpected event, no state change;

2.4 Ground Start PBX

Table 2-4/C-IF3.01 shows the WAC analogue subscribe interface state transition table for ground start PBX.

Table 2-4/C-IF3.01 Interface State Transition Table, Ground Start PBX

| state | ST 0 | ST 1 | ST 2 |
|----------------------------|-----------------------------|---|-------------------|
| event | | | |
| SN dt | SEIZURE ACK | SEIZURE ACK | / |
| SN bt | / | / | / |
| SN howler | / | / | / |
| SN ringing | TERMINATING, ST 2 | / | / |
| SN normal polarity | NORMAL POLARITY | NORMAL POLARITY | / |
| SN reverse polarity | / | REVERSE POLARITY | / |
| SN loop closed | / | / | / |
| SN loop open | / | / | / |
| SN dp/dtmf | / | / | / |
| SN g on tip | / | / | / |
| SN meter pulsing signal | / | / | / |
| off hook | g on tip with loop, ST 1 | / | loop closed, ST 1 |
| on hook | / | loop open and remove g on tip, ST 0 | / |
| digit dial | / | dp/dtmf | / |
| reverse polarity | / | / | / |
| normal polarity | / | / | / |

- = No state change; / = Unexpected event, no state change;

2.5 DDI PBX

Table 2-5/C-IF3.01 (1/2) shows the WAC analogue subscribe interface state transition table for DDI PBX, originating.

Table 2-5/C-IF3.01 (2/2) shows the WAC analogue subscribe interface state transition table for DDI PBX, terminating.

Table 2-5/C-IF3.01 (1/2) Interface State Transition Table, DDI PBX, Originating

| state | ST 0 | ST 1 |
|-------------------------|-------------------|------------------|
| event | | |
| SN dt | SEIZURE ACK | SEIZURE ACK |
| SN bt | / | / |
| SN howler | / | / |
| SN ringing | / | / |
| SN normal polarity | NORMAL POLARITY | NORMAL POLARITY |
| SN reverse polarity | / | REVERSE POLARITY |
| SN loop closed | / | / |
| SN loop open | / | / |
| SN dp/dtmf | / | / |
| SN g on tip | / | / |
| SN meter pulsing signal | / | / |
| off hook | loop closed, ST 1 | / |
| on hook | / | loop open, ST 0 |
| digit dial | / | dp/dtmf |
| reverse polarity | / | / |
| normal polarity | / | / |

- = No state change; / = Unexpected event, no state change;

Table 2-5/C-IF3.01 (2/2) Interface State Transition Table, DDI PBX, Terminating

| state | ST 0 | ST 1 | ST 2 | ST 3 | ST 4 |
|-------------------------|-------------------|-----------------------|------------------------|-----------------------|------------------------|
| event | | | | | |
| SN dt | / | / | / | / | / |
| SN bt | / | / | / | / | / |
| SN howler | / | / | / | / | / |
| SN ringing | / | / | / | / | / |
| SN normal polarity | / | / | / | / | / |
| SN reverse polarity | / | / | / | / | / |
| SN loop closed | TERMINATING, ST 2 | / | / | / | / |
| SN loop open | / | RELEASE, ST 3 | / | / | RELEASE, ST 0 |
| SN dp/dtmf | / | / | DIGIT DIAL | / | / |
| SN g on tip | / | / | / | / | / |
| SN meter pulsing signal | / | / | / | / | / |
| off hook | / | / | / | / | / |
| on hook | / | / | / | / | / |
| digit dial | / | / | / | / | / |
| reverse polarity | / | / | reverse polarity, ST 1 | / | reverse polarity, ST 1 |
| normal polarity | / | normal polarity, ST 4 | / | normal polarity, ST 0 | / |

- = No state change; / = Unexpected event, no state change;

2.6 NTT individual Subscriber

State transition table of NTT individual subscriber is same as loop start PBX

2.7 NTT DDI PBX

State transition table of NTT DDI PBX, originating is same as loop start PBX.

Terminating table is in table 2-6/C-IF3.01

Table 2-6/C-IF3.01 Interface State Transition Table, NTT DDI PBX, Terminating

| state | ST 0 | ST 1 | ST 2 |
|----------------------------|----------------------|--------------------|-------------------|
| event | | | |
| SN dt | / | / | / |
| SN bt | / | / | / |
| SN howler | / | / | / |
| SN ringing | TERMINATING, ST 2 | / | / |
| SN normal polarity | / | / | / |
| SN reverse polarity | REVERSE POLARITY | / | / |
| SN loop closed | / | / | / |
| SN loop open | / | / | / |
| SN dtmf | / | DIGIT SIGNAL | / |
| SN g on tip | / | / | / |
| SN meter pulsing signal | / | / | / |
| off hook | loop closed, ST 1 | / | loop closed, ST 1 |
| on hook | / | loop open, ST 0 | / |
| digit dial | / | / | / |
| reverse polarity | / | / | / |
| normal polarity | / | NORMAL POLARITY | / |

- = No state change; / = Unexpected event, no state change;

3. Message Sequence Examples

3.1 Originating-Answer (Individual DP Line Sub.)

Figure 3-1/C-IF3.01 shows a WIF3 sequence of originating answer (Individual DP Line Subscriber).




Figure 3-1/C-IF3.01 Originating - Answer (Individual DP Line Sub.)

3.2 Originating-Answer (Individual DTMF Line Sub.)

Figure 3-2/C-IF3.01 shows a WIF3 sequence of originating answer (Individual DTMF Line Subscriber).




Figure 3-2/C-IF3.01 Originating - Answer (Individual DTMF Line Sub.)

3.3 Originating-Answer (Loop Start PBX)

Figure 3-3/C-IF3.01 shows a WIF3 sequence of originating answer (Loop Start PBX).




Figure 3-3/C-IF3.01 Originating - Answer (Loop Start PBX)

3.4 Originating-Answer (Ground Start PBX)

Figure 3-4/C-IF3.01 shows a WIF3 sequence of originating answer (Ground Start PBX).




Figure 3-4/C-IF3.01 Originating - Answer (Ground Start PBX)

3.5 Release-before Dialling

Figure 3-5/C-IF3.01 shows a WIF3 sequence of release before dialling.




Figure 3-5/C-IF3.01 Release - before Dialling

3.6 Release-during Dialling

Figure 3-6/C-IF3.01 shows a WIF3 sequence of release during dialling.




Figure 3-6/C-IF3.01 Release - during Dialling

3.7 Release-During Ringing

Figure 3-7/C-IF3.01 shows a WIF3 sequence of release during ringing.




Figure 3-7/C-IF3.01 Release - during Ringing

3.8 Call Collision

Figure 3-8/C-IF3.01 shows a WIF3 sequence of call collision.

(This sequence is completely same as originating sequence.)

Figure 3-8/C-IF3.01 Call Collision

3.9 Calling Party Release-Individual Sub. Originating

Figure 3-9/C-IF3.01 shows a WIF3 sequence of calling party release individual subscriber originating.




Figure 3-9/C-IF3.01 Calling Party Release - Individual Sub Originating

3.10 Called Party Release-Individual Sub. Originating

Figure 3-10/C-IF3.01 shows a WIF3 sequence of called party release individual subscriber originating.




Figure 3-10/C-IF3.01 Called Party Release - Individual Sub Originating

3.11 Terminating-Answer

Figure 3-11/C-IF3.01 shows a WIF3 sequence of terminating answer.




Figure 3-11/C-IF3.01 Terminating - Answer

3.12 Terminating-Ringing Resource Hunt NG

Figure 3-12/C-IF3.01 shows a WIF3 sequence of terminating ringing resource hunt NG.




Figure 3-12/C-IF3.01 Terminating - Ringing Resource Hunt NG

3.13 Terminating-Answer (NTT DDI Spec.)

Figure 3-13/C-IF3.01 shows a WIF3 sequence of terminating answer (NTT DDI Specification).




Figure 3-13/C-IF3.01 Terminating - Answer (NTT DDI Spec)

3.14 Terminating-Answer (DP type DDI)

Figure 3-14/C-IF3.01 shows a WIF3 sequence of terminating answer (DP type DDI).




Figure 3-14/C-IF3.01 Terminating - Answer (DP Type DDI)

3.15 Terminating-Answer (DTMF Type DDI)

Figure 3-15/C-IF3.01 shows a WIF3 sequence of terminating answer (DTMF type DDI).




Figure 3-15/C-IF3.01 Terminating - Answer (DTMF Type DDI)

3.16 Calling Party Release-Individual Sub. Terminating

Figure 3-16/C-IF3.01 shows a WIF3 sequence of calling party release individual subscriber terminating.




Figure 3-16/C-IF3.01 Calling Party Release - Individual Sub Terminating

3.17 Called Party Release-Individual Sub. Terminating

Figure 3-17/C-IF3.01 shows a WIF3 sequence of called party release individual subscriber terminating.




Figure 3-17/C-IF3.01 Called Party Release - Individual Sub Terminating

3.18 Hooking Monitoring

Figure 3-18/C-IF3.01 shows a WIF3 sequence of hooking monitoring.




Figure 3-18/C-IF3.01 Hooking Monitoring

3.19 Meter Pulsing Signal Sending

Figure 3-19/C-IF3.01 shows a WIF3 sequence of meter pulsing signal sending.




Figure 3-19/C-IF3.01 Meter Pulsing Signal Sending

3.20 Connection to Howler Tone

Figure 3-20/C-IF3.01 shows a WIF3 sequence of connection to howler tone.




Figure 3-20/C-IF3.01 Connection to Howler Tone